

Direct Electrolytic Reduction of Oxides

Karthick Gourishankar, Laszlo Redey and Mark Williamson
Chemical Engineering Division, Argonne National Laboratory

Introduction


- Goal: Extend pyroprocessing to include treatment of spent light water reactor fuel to reduce burden on repository
 - Recover actinides for consumption as fuel in advanced fast reactor
 - Produce durable, leach-resistant waste forms to encapsulate fission products
- Successful development of a process to reduce actinide-oxides to metals is a key step in achieving the goal
- Direct electrolytic reduction selected for conversion of spent actinide oxides to metals because of high product quality, high throughput, simple engineering, and compatibility with electrolyzer technology




Argonne chemist tests metal oxide conversion process

Direct Electrolytic Reduction – Process Description


Electrochemical process converts metal oxides to metals, a solid-state transformation, using electrons



UO₂ Feed




Partially Reduced Product



Fully Reduced Product

Direct Electrolytic Reduction Demonstrated with UO₂ and UO₂-5wt% PuO₂ Feeds





UO₂ Reduction with Periodic Current Interrupts – Stable Cell Performance Achieved

UO₂ Reduction Mechanism by Coulometric Titration

Electrochemical reduction of UO₂ involves multi-step electron transfer reactions

Formation of Intermediate Phases Possible

- Electrochemical evidence of multiple stable rest potentials characterizing electrolytic reduction of UO₂
- Formation of intermediate compounds such as Li₂U₂O₇ may explain the observation of stable rest potentials in UO₂ reduction
- For an oxide, M_xO_y, the postulated solid-state reduction mechanism is summarized by the reaction sequence:



High-Capacity Reduction (HCR) Cell


HCR cells designed to provide electrochemical engineering data needed for pilot-scale cell design



HCR cells handle kg-scale feeds and large volumes of evolved oxygen

HCR Cathode Product

- Complete conversion of 1kg UO₂ feed to U-metal
- Entrained salt in product ~12 wt%
- Stable and reproducible cell performance



Tracking Reduction in HCR Cells

Monitoring O₂ in off-gas reveals reduction status and *in-situ* current efficiency

HCR Test Results

- Instantaneous Current Efficiency**

$$\eta = i_{\text{O}_2} / i$$
 where i_{O_2} = instantaneous O₂ flux (current equivalent)
 i = instantaneous cell current
Average Current Efficiency – 65%
 - 465 Ah passed
 - 300 Ah theoretical required for 750 g UO₂
- Total Oxygen Removed from Cell**

$$\omega = \int i_{\text{O}_2} dt$$
Extent of Reduction
 - 99.5% by chemical analysis of product
 - 97% by integrating instantaneous oxygen removed from cell

Summary

- Direct electrolytic reduction demonstrated using
 - UO₂
 - UO₂-5wt% PuO₂
- Demonstrated >99% conversion of UO₂, PuO₂, and AmO₂
- Reduction rates are very good
- UO₂ reduction mechanism involves multi-step electron transfer reactions
- HCR cells have incorporated enhanced O₂-handling and process monitoring features