




Catalytic Chemistry in Supercritical Fluids

Over 90% of industrial chemical processes entail the use of catalysts, and nearly half of these are homogeneous catalytic processes in which the catalyst is dissolved in a fluid. We have pioneered in research investigating catalytic reactions in supercritical fluids.

Supercritical fluids such as CO₂ and water offer inexpensive and environmentally benign alternatives to the toxic organic solvents that are commonly used in homogeneous catalysis. An additional advantage is the elimination of energy-intensive distillations necessary for product separations and catalyst recovery from organic solvents. Our recent research has focused on the development of phosphine-modified cobalt catalysts for the hydroformylation of olefins in supercritical CO₂.


The hydroformylation of olefins, also known as the oxo reaction, is the largest industrial process that is catalyzed by homogeneous catalysts. This process, which is usually conducted in organic media, converts olefins to aldehydes, as exemplified with ethylene:




While rhodium catalysts account for most of the C₄ hydroformylation products, oxo reactions producing C₅ and higher products are dominated by cobalt over rhodium catalysts by a ratio of 9 to 1. The primary advantage of cobalt catalysts is their higher reactivity toward internal olefins. The phosphine-modified cobalt catalyst process, which was discovered and is used exclusively by Shell Chemical Co., differs from the unmodified cobalt carbonyl catalyst Co₂(CO)₈ in that the presence of a tertiary phosphine improves the selectivity toward the linear products. Our interest in Shell's hydroformylation process stems from its industrial

importance and the fact that the phosphine ligand provides for easy modification to produce cobalt catalysts that are soluble in supercritical CO₂.

In our earlier study of Shell's phosphine-modified cobalt catalyst system with tributylphosphine in organic solvents, we discovered that [Co(PBu₃)₂(CO)₃][Co(CO)₄] was produced under the oxo reaction conditions according to



The reaction reduces the concentration of Co₂(PBu₃)₂(CO)₆, and, therefore, the concentration of the key hydride intermediate, HCo(PBu₃)(CO)₃. This intermediate species is generated from Co₂(PBu₃)₂(CO)₆ as follows:



This salt formation presented a particular challenge for the development of supercritical CO₂ as a solvent for the phosphine-modified hydroformylation reaction since this supercritical fluid is known to be a poor solvent for salts. We found that all of the cobalt species precipitated from supercritical CO₂ using highly basic phosphines, such as PBu₃.

We approached this problem by fine tuning the phosphine ligand to decrease the basicity with the goal of reducing the driving force for salt formation. Furthermore, the use of fluorine substituents had the additional advantage of enhancing the solubility of the cobalt complexes in supercritical CO₂. Accordingly, we have synthesized Co₂[P(C₆H₄CF₃)₃]₂(CO)₆ and showed that it catalyzes the hydroformylation of ethylene (see first reaction above) in supercritical CO₂ with a rate comparable to that of the unsubstituted cobalt carbonyl catalyst. A great surprise was the


discovery that with a 1:1 ratio of CO/H₂ gas, this catalyst continued to function until all the CO/H₂ was consumed, as shown by the curve so labeled in the figure below. For comparison, this figure also shows the curve obtained for the consumption of H₂ with the unsubstituted Co₂(CO)₈ under similar conditions. This reaction stopped when the CO pressure (the same as H₂) reached 4.5 atm, because of decomposition of the catalyst. The presence of the P(C₆H₄CF₃)₃ ligand apparently stabilizes the catalyst at 100°C without the need of a CO pressure.

We have thus shown that P(C₆H₄CF₃)₃-substituted cobalt carbonyl catalyst is active in catalyzing the hydroformylation of ethylene. The results further

show that the hydroformylation reaction may be carried out at atmospheric pressure. For practical consideration, it is desirable to carry out the reaction at moderate pressures to reduce capital equipment costs. The main advantage for this catalyst is that the reaction may be carried out until all the CO and H₂ are used up, eliminating the need to recycle these gaseous reactants. At the end of the reaction, all that is required is to isolate the products from supercritical CO₂, a very simple process.

ANL Participants

Michael J. Chen, Robert J. Klingler, and Jerome W. Rathke. For further information, contact Michael Chen at (630) 252-5258 or chenm@cmt.anl.gov.



Rate Plots for the Hydroformylation of Ethylene with and without Phosphine Additive

Test conditions: 100°C, [H₂] = [CO] = 1.1 M, [C₂H₄] = 2.0 M, and CO₂ partial pressure = 119 atm. Triangles indicate [Co₂(CO)₈] = 4.1 mM; circles, [Co₂(CO)₆L₂] = 4.1 mM and P(C₆H₄CF₃)₃ = 74 mM.